




Lotus



- | | |
|-----------------------------|----------------------------------|
| (D) Montageanleitung | (GB) Assembly instructions |
| (FR) Notice de montage | (NL) Handleiding voor de montage |
| (CZ) Montážní návod | (IT) Istruzioni di montaggio |
| (RO) Instrucțiuni de montaj | (RU) инструкция по сборке |
| (PL) Instrukcja montażu | (SK) Návod na montáž |
| (HU) Szerelési útmutató | (TR) Montaj talimatı |



Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam
Nazwa • Jméno • Názov • Név
Denumire • İsim • Название






Lotus zerl.

Nr. • No. • N° • Номер • Č • Sz

SH55


Typ • Type • Tip • Típus • Tipo
Тип

LARO




A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
2x	20x 4,5x20	2x 6x35	2x 6x45	2x 4,5x45	2x 6x30	2x M8	2x M5	2x M5	2x 4,5x20	2x	2x 8x45	6x 8x20	6x M8	4x 8x60



1.




1




Handfestanziehen
 Ne serrez pas
 Nedotahujte
 Nu strângeți
 Nie dokręcać
 Ne hűzza meg
 Do not tighten
 Nog niet vastdraaien
 Non serrare
 Не затягивайте
 Nedotahujte
 Sıkmayın



2



Handfestanziehen
 Ne serrez pas
 Nedotahujte
 Nu strângeți
 Nie dokręcać
 Ne hűzza meg
 Do not tighten
 Nog niet vastdraaien
 Non serrare
 Не затягивайте
 Nedotahujte
 Sıkmayın




2.





Schrauben fest anziehen
 Serrer les vis
 Utáhněte šrouby
 Strângeți șuruburile
 Dokrećić šrubby
 Húzza meg a csavarokat
 Tighten the screws
 Draai de schroeven
 Serrare le viti
 Затянуть винты
 Utiahnite skrutky
 Vidaları sıkın

3.






4.



5.



6.




7.





M		4x 8x60
N		4x M8
O		4x M8



KT_4xGEW_8x60