





- (D) Montageanleitung
- (NL) Handleiding voor de montage
- (HU) Szerelési útmutató
- (GB) Assembly instructions



- (PL) Instrukcja montażu
- (RO) Instrucțiuni de montaj
- (FR) Notice de montage
- (CZ) Montážní návod
- (TR) Montaj talimatı
- (IT) Istruzioni di montaggio
- (SK) Návod na montáž
- (RU) Инструкция по монтажу

**Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба**


Name • Nom • Nome • Naam •
Nazwa • Jméno • Název • Név •
Denumire • Isim • Название

Nr. • No. • N° • Номер • Č • Sz


Typ • Type • Tip • Tipus • Tipo •
Тип







1	1x	ca. 2002 x 330 mm	7	2x	ca. 1074 x 172 mm
2	1x	ca. 1981 x 330 mm	8	2x	ca. 1044 x 307 mm
3	1x	ca. 2002 x 330 mm	9-L	2x	ca. 310 x 104 mm
4	2x	ca. 318 x 330 mm	9-M	2x	ca. 1032 x 104 mm
5	1x	ca. 318 x 315 mm	9-R	2x	ca. 310 x 104 mm
6	1x	ca. 318 x 315 mm	10	2x	ca. 347 x 459 mm




A 8,0 x 30 mm 16x	B 16x	C 16x	D 6x	E 3,9 x 9,5 mm 12x	F 7x	G 4,0 x 20 mm 7x
H Ø35 Kr.0 4x	I h=2 4x	J M4,0 x 9 mm 4x	K 2,7 x 20 mm 6x	L 27 x 310 mm 4x	M 6,3 x 13 mm 16x	
N 1x	O 8x					




1



2

A 8,0 x 30 mm  16x	B  16x	C  16x	I  h=2 4x	L 27 x 310 mm  4x	M 6,3 x 13 mm  8x
D  6x	E 3,9 x 9,5 mm  12x				



MA2


3

M 6,3 x 13 mm
8x



O
8x

N
1x

D Leim
GB Glue
FR Colle
IT Colla
NL Lijm
PL Klej
CZ Lepidlo
SK Glej
HU Enyv
RO Adeziv
TR Tutkal
RU Клей





4




5

J M4,0 x 9 mm
4x




➔ 8 / 9




- (D) Push-To-Open einstellen
- (GB) Adjusting the Push-To-Open
- (FR) Régler les Push-To-Open
- (IT) Sistemare Push-To-Open
- (NL) Push-To-Open instellen
- (PL) Nastawić Push-To-Open
- (CZ) Vyrovnajte Push-To-Open
- (RO) Nastavenie Push-To-Open
- (HU) Állítsa be az Push-To-Open
- (SK) Reglare Push-To-Open
- (TR) Push-To-Open ayarlanması
- (RU) Регулировка Push-To-Open

➔ 9 / 9



- (D) Türen einstellen
(Scharniere justieren)
- (GB) Adjusting the doors
(adjusting the hinges)
- (FR) Régler les portes
(ajuster les charnières)
- (IT) Sistemare le porte
(regolare le cerniere)
- (NL) Deuren instellen
(scharnieren afstellen)
- (PL) Nastawić drzwi
(wyregulować zawiasy)
- (CZ) Vyrovnajte dvířka
(seříd'te závěsy)
- (RO) Nastavenie dverí
(nastavenie závesov)
- (HU) Állítsa be az ajtókat
(állítsa be a zsanérokot)
- (SK) Reglare uši
(ajustare balamale)
- (TR) Kapıların ayarlanması
(menteşelerin seviye ayarı)
- (RU) Регулировка дверей
(регулировка шарнира)

6



(D) Push-To-Open einstellen

(GB) Adjusting the Push-To-Open

(FR) Régler les Push-To-Open

(IT) Sistemare Push-To-Open

(NL) Push-To-Open instellen

(PL) Nastawić Push-To-Open

(CZ) Vyrovnajte Push-To-Open

(RO) Nastavenie Push-To-Open


(HU) Állítsa be az Push-To-Open

(SK) Reglare Push-To-Open



(TR) Push-To-Open ayarlanması


(RU) Регулировка Push-To-Open

1.



2.





- (D) Türen einstellen
(Scharniere justieren)
- (GB) Adjusting the doors
(adjusting the hinges)
- (FR) Régler les portes
(ajuster les charnières)
- (IT) Sistemare le porte
(regolare le cerniere)
- (NL) Deuren instellen
(scharnieren afstellen)
- (PL) Nastawić drzwi
(wyregulować zawiasy)

- (CZ) Vyrovnajte dvířka
(seřid'te závěsy)
- (RO) Nastavenie dverí
(nastavenie závesov)
- (HU) Állítsa be az ajtókat
(állítsa be a zsanérokot)
- (SK) Reglare uši
(ajustare balamale)
- (TR) Kapıların ayarlanması
(menteşelerin seviye ayarı)
- (RU) Регулировка дверей
(регулировка шарнира)

