



- | | |
|--------------------------------|----------------------------|
| Ⓓ Montageanleitung | ⒼⒷ Assembly instructions |
| ⒻⓇ Notice de montage | ⒾⓉ Istruzioni di montaggio |
| ⓃⓁ Handleiding voor de montage | ⓅⓁ Instrukcja montażu |
| ⒸⓏ Montážní návod | ⓈⓀ Návod na montáž |
| ⒽⓊ Szerelési utmutató | Ⓡⓞ Instrucțiuni de montaj |
| ⓉⓇ Montaj talimatı | ⓇⓊ Инструкция по монтажу |

Ausgabe: 20190904



Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam
Nazwa • Jméno • Názov •
Név
Denumire • Isim • Название




SALTAIRE

Nr. • No. • N° • Номер • Č.
Sz


1813 8062

Typ • Type • Tip • Típus •
Tipo
Тип




YS-CT6276



A M6X12MM  X8	B D15  X28	C  X28	D D12  X6	E  X6
F M4X25MM  X4	G M4X35MM  X14	H  X12	J  X1	K  X4



1




2

K



X4




3

B

D15



X4




4

B

D15



X3




5

B

D15



X3




6

B

D15



X18



7

A

M6X12MM




X12

M




X1




8


G	M4X35MM	K	
			
X14		X4	




9



D	D12	E	M4X25MM
			
X6		X6	
		X4	



10



11

