





- (D) Montageanleitung
 (GB) Assembly instructions
 (NL) Handleiding voor de montage



- (HU) Szerelési útmutató
 (PL) Instrukcja montażu
 (RO) Instrucțiuni de montaj



- (FR) Notice de montage
 (CZ) Montážní návod
 (TR) Montaj talimatı
 (IT) Istruzioni di montaggio
 (SK) Návod na montáž
 (RU) Инструкция по монтажу

Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam •
Nazwa • Jméno • Názov • Név •
Denumire • Ísim • Название


Nr. • No. • N° • Номер • Č • Sz

Tур • Type • Tip • Típus • Tipo •
Тип



1	1x	ca. 1385 x 350 mm
2	1x	ca. 1366 x 680 mm
3	1x	ca. 1385 x 330 mm
4	2x	ca. 668 x 330 mm
5	1x	ca. 668 x 315 mm
6	1x	ca. 668 x 315 mm



7	3x	ca. 459 x 224 mm
8	3x	ca. 428 x 307 mm
9	3x	ca. 1081 x 89 mm
10	2x	ca. 437 x 300 mm
11	1x	ca. 680 x 459 mm
12	1x	ca. 680 x 459 mm






A 8,0 x 30 mm 16x	B 16x	C 16x	D 3,9x9,5mm 5x	E h=2 4x	F Ø26 Kr.0 4x	G 1x
H 4,0 x 20 mm 8x	I 8x	J 2,7 x 20 mm 8x	K 6,3 x 13 mm 12x	L 17 x 310 mm 6x	M M4,0 x 9 mm 6x	N 8x



1











D Leim
GB Glue
FR Colle
IT Colla
NL Lijm
PL Klej
CZ Lepidlo
SK Glej
HU Enyv
RO Adeziv
TR Tutkal
RU Клей



20min







2












3

A 8,0 x 30 mm  8x	B  8x	C  8x	E h=2  4x
---	---	---	---





4



A 8,0 x 30 mm	C 	D  3,9x9,5mm	L 17 x 310 mm	K 6,3 x 13 mm
 8x	 8x	 5x	 6x	 12x





5



6





7



8

M M4,0 x 9 mm
6x






➔ 11 / 12

(D) **Push-To-Open** einstellen
 (GB) Adjusting the Push-To-Open
 (FR) Régler les Push-To-Open
 (IT) Sistemare Push-To-Open
 (NL) Push-To-Open instellen
 (PL) Nastawić Push-To-Open
 (CZ) Vyrovnajte Push-To-Open
 (RO) Nastavenie Push-To-Open
 (HU) Állítsa be az Push-To-Open
 (SK) Reglare Push-To-Open
 (TR) Push-To-Open ayarlanması
 (RU) Регулировка Push-To-Open


➔ 12 / 12

(D) **Türen einstellen**
 (Scharniere justieren)
 (GB) Adjusting the doors
 (adjusting the hinges)
 (FR) Régler les portes
 (ajuster les charnières)
 (IT) Sistemare le porte
 (regolare le cerniere)
 (NL) Deuren instellen
 (scharnieren afstellen)
 (PL) Nastawić drzwi
 (wyregulować zawiasy)
 (CZ) Vyrovnajte dvířka
 (seřid'te závěsy)
 (RO) Nastavenie dverí
 (nastavenie závesov)
 (HU) Állítsa be az ajtókat
 (állítsa be a zsanérokat)
 (SK) Reglare uși
 (ajustare balamale)
 (TR) Kapıların ayarlanması
 (menteşelerin seviye ayarı)
 (RU) Регулировка дверей
 (регулировка шарнира)








(D) Push-To-Open einstellen (GB) Adjusting the Push-To-Open (FR) Régler les Push-To-Open (IT) Sistemare Push-To-Open (NL) Push-To-Open instellen (PL) Nastawić Push-To-Open	(CZ) Vyrovnejte Push-To-Open (RO) Nastavenie Push-To-Open (HU) Állítsa be az Push-To-Open (SK) Reglare Push-To-Open (TR) Push-To-Open ayarlanması (RU) Регулировка Push-To-Open
---	---

1.



2.





(D) Türen einstellen
(Scharniere justieren)

(GB) Adjusting the doors
(adjusting the hinges)

(FR) Régler les portes
(ajuster les charnières)

(IT) Sistemare le porte
(regolare le cerniere)

(NL) Deuren instellen
(scharnieren afstellen)

(PL) Nastawić drzwi
(wyregulować zawiasy)

(CZ) Vyrovnajte dvířka
(seřid'te závěsy)

(RO) Nastavenie dverí
(nastavenie závesov)

(HU) Állítsa be az ajtókat
(állítsa be a zsanérokat)

(SK) Reglare uši
(ajustare balamale)

(TR) Kapıların ayarlanması
(menteşelerin seviye ayarı)

(RU) Регулировка дверей
(регулировка шарнира)

