


CHELSEA HOCKER 80x80



15min



(D) Montageanleitung

(NL) Handleiding voor de montage

(TR) Montaj talimati

(F) Notice de montage

(CZ) Montážní návod

(GB) Assembly instructions

(HU) Szerelési útmutató



(PL) Instrukcja montażu

(RU) Инструкция по монтажу


(IT) Istruzioni di montaggio

(SK) Návod na montáž

(RO) Instrucțiuni de montaj




A




x1

B




x4

C




x24






D



x1








0-6




Service • Assistenza • Dienstverlening • Serwis •
 Servis • Szerviz • Сервисная служба


Name • Nom • Nome • Naam • Nazwa • Jméno • Název • Név • Denimire • Isim • Название	CHELSEA
Nr • No. • N° • Номер • Č • Sz	80x80
Type • Tipo • Típus • Typ • Тип • Тип	HOCKER




x...



x...



x...



x...