



Hamilton




- | | |
|-----------------------------|----------------------------------|
| (D) Montageanleitung | (GB) Assembly instructions |
| (FR) Notice de montage | (NL) Handleiding voor de montage |
| (CZ) Montážní návod | (IT) Istruzioni di montaggio |
| (RO) Instrucțiuni de montaj | (RU) инструкция по сборке |
| (PL) Instrukcja montażu | (SK) Návod na montáž |
| (HU) Szerelési útmutató | (TR) Montaj talimati |



0
10
20
30
40
50
60
70
80
90
100
110
120
130
140
150
160
170
180
190
200


Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба	
Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • Ísim • Название	Hamilton DB
Nr. • No. • N° • Номер • Č • Sz	SH42
Typ • Type • Tip • Típus • Тіро Тип	OHNE



A	B	C	D	E	F	G	H
4x	1x 6x45	1x M6	1x M6	1x M6	2x 8x60	2x M8	2x M8






0
10
20
30
40
50
60
70
80
90
100
110
120
130
140
150
160
170
180
190
200


Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба	
Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • Ísim • Название	Hamilton DB
Nr. • No. • N° • Номер • Č • Sz	SH42
Typ • Type • Tip • Típus • Тіро Тип	LARO






A	B	C	D	E	F	G	H
4x	1x 6x45	1x M6	1x M6	1x M6	2x 8x60	2x M8	2x M8



A		4x
B		1x 6x45
C		1x M6
D		1x M6
E		1x M6





F		H	
	2x 8x60	G	
			2x M8

